

Plastic Mini Trigger Sprayer 24410 28410

Specifications :

--

Detail Introduction :

Plastic Mini Trigger Sprayer 24410 28410



<p>LOTTION PUMP 乳液泵</p> <p>LEFT-RIGHT LOTION PUMP 开关泵</p>																				
	<p>JM-L11-2 JM-L11-3 JM-L11-4 JM-L12 JM-L12-1 JM-L12-2 JM-L12-3 JM-L13 JM-L14 JM-L14 030/400 030/410 030/410 032/410 032/400 032/400 032/400 024/410 028/410 024/410 028/410</p>	<p>JM-L15 JM-L15 JM-L16 JM-L16 JM-L17 JM-L17 JM-L18 JM-L18 JM-L19 JM-L19 JM-L20 024/410 028/410 024/410 028/410 024/410 028/410 024/410 028/410 024/410 028/410 024/410</p>	<p>JM-L20 JM-L21 JM-L21 JM-L22 JM-L23 JM-L001 JM-L01-1 JM-L01-2 JM-L01-3 JM-L01-4 JM-L01-5 028/410 024/410 028/410 024/415 028/415 024/410 024/410 024/410 024/410 024/410 024/410</p>	<p>JM-L01-6 JM-L01-7 JM-L01-8 JM-L01-9 JM-L01-10 JM-L01-11 JM-L01-12 JM-L002 JM-L02-1 JM-L02-2 024/410 024/410 024/410 024/410 024/410 024/410 024/410 028/410 028/410 028/410</p>	<p>JM-L02-3 JM-L02-4 JM-L02-5 JM-L003 JM-L03-2 JM-L03-3 JM-L004 JM-L04-1 JM-L04-2 JM-L04-3 028/410 028/410 028/410 028/400 024/415 028/415 024/410 024/410 024/415 028/410</p>	<p>JM-L04-4 JM-L005 JM-L05-1 JM-L05-2 JM-L05-3 JM-L05-4 JM-L05-5 JM-L05-6 JM-L006 JM-L006-1 028/410 028/410 028/410 028/410 028/415 024/415 028/410 028/410 024/410 024/410</p>	<p>JM-L006-2 JM-L007 JM-L07-1 JM-L008 JM-L009 JM-L09-1 JM-L010 JM-L010-1 JM-L011 JM-L012 028/410 024/410 028/410 028/400 028/410 028/410 028/410 028/410 028/410 024/410</p>	<p>JM-T01 JM-T01 JM-T01 JM-T02 JM-T02 JM-T02 JM-T03 JM-T03 028/400 028/410 028/415 028/400 028/410 028/415 028/400 028/410</p>	<p>JM-T03 JM-T04 JM-T04 JM-T04 JM-T05 JM-T05 JM-T05 JM-T06 JM-T06 028/415 028/400 028/410 028/415 028/400 028/410 028/415 028/400</p>	<p>JM-T06 JM-T06 JM-T07 JM-T07 JM-T07 JM-T08 JM-T08 JM-T08 028/410 028/415 028/400 028/410 028/415 028/400 028/410 028/415</p>	<p>JM-T09 JM-T09 JM-T09 JM-T10 JM-T10 JM-T10 JM-T11 JM-T11A 028/410 028/410 028/415 028/400 028/410 028/415 028/410 028/410</p>	<p>JM-T11B JM-T11B-1 JM-T11B-2 JM-T11C JM-T11C-1 JM-T11C-2 JM-T11D JM-T11D 028/400 028/400 028/410 028/400 028/400/410 028/400/410 028/400 028/410</p>	<p>JM-T12 JM-T12-1 JM-T12-1 JM-T13 JM-T13-1 JM-T14 JM-T14 JM-T15 028/400 028/400 028/410/415 028/400/410 028/400/410 028/400 028/410/415 028/400/410</p>	<p>JM-T15-1 JM-T16 JM-T16-1 JM-T17 JM-T18 JM-T18-1 JM-T19 JM-T19-1 028/400/410 024/410 028/400 028/400/410 028/410 028/400 028/410 028/400</p>	<p>JM-T20 JM-T21 JM-T22 JM-T22 JM-T22 JM-T22 JM-T23 JM-T23 028/410 028/400 028/400 028/410 028/415 028/410 028/410</p>	<p>TRIGGER SPRAYER 手扣式喷头</p>				

FOAM TRIGGER SPRAYER 泡沫喷枪

MINI TRIGGER 小老鼠喷枪

TREATMENT PUMP 粉泵



TREATMENT PUMP 粉泵

PLASTIC CAP 塑料盖子



